



检测报告

Test Report

送检企业: 中陇建工集团有限公司

样品名称: 塑料管 200PvC-U 管

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



样品名称	: 塑料管 200PvC-U 管	型号规格	: /
商标	: /	样品数量	: 1 组
委托单位	: 中陇建工集团有限公司		
委托单位地址	: 江西省贵溪市沿河路以北、冶金大道以西和道华庭 S5#楼 219 号		
生产单位	: /		
生产单位地址	: /		
检验类别	: 委托检验	测试日期	: 2025 年 03 月 12 日-2025 年 03 月 24 日
签发日期	: 2025 年 03 月 24 日		
检验依据	: 见附页		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制: 张华伟

报告审核: 杨泽群



报告签发: 杨泽群



报告编号: HYI202503240H218

序号	检测项目		检测依据	指标要求	检测结果	单项判定
1	颜色		GB/T10002.1-2006	协议色白色	白色	符合
2	外观		GB/T10002.1-2006	管材表面颜色应均匀一致, 不应有明显色差。管材的内外表面应光滑、平整, 不应有凹陷、气泡、杂质及其他影响性能的表面缺陷。管材端面应切割平整并与管材的轴线垂直。	管材表面颜色均匀一致, 无明显色差。管材的内外表面光滑、平整, 无凹陷、气泡、杂质及其他影响性能的表面缺陷。管材端面切割平整并与管材的轴线垂直。	符合
3	规格及尺寸	平均外径, mm	GB/T 8806- 2008	160.0 ~ 160.5	160.1 ~ 160.3	符合
		壁厚, mm	GB/T 8806- 2008	17.9 ~ 19.9	18.0 ~ 18.1	符合
4	静液压强度(95 C,1000h)		GB/T 6111- 2018	无破裂、无渗漏	无破裂、无渗漏	符合
5	密度, kg/m ³		GB/T 1033.1- 2008	1450 ~ 1650	1607	符合
6	维卡软化温度, °C		GB/T 8802- 2001	≥82	112	符合
7	纵向回缩率, %		GB/T 6671- 2001	≤1.5	1.1	符合

检测专用章

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com