



检测报告

Test Report

送检企业: 泰州驰晟体育器材有限公司

样品名称: 预制型塑胶面及配套胶粘剂

检验类别: 委托检验

厦门泓益检测有限公司

检测专用章

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202500711A3129

样品名称	: 预制型塑胶面及配套胶粘剂	型号规格	: /
商标	: 驰晟	样品数量	: 2 pcs
委托单位	: 泰州驰晟体育器材有限公司		
委托单位地址	: /		
生产单位	: 泰州驰晟体育器材有限公司		
生产单位地址	: /		
检验类别	: 委托检验	测试日期	: 2025年06月18日-2025年07月11日
签发日期	: 2025年07月11日		
检验依据	: GB 36246-2018《中小学合成材料面层运动场地》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

检测专用章

报告签发: 杨泽群

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



(一) 预制型塑胶跑道面层 (用于田径场地, 非渗水型)

检测项目	子项目	技术要求	检测结果	单项判定
厚度	-	符合设计要求, 且不低于 13mm	平均值 14.8mm (满足设计要求, 符合 ≥ 13 mm 要求)	合格
冲击吸收	-	田径场地: 35%-50%	平均值 42% (田径场地, 符合 35%-50% 要求)	合格
垂直变形	-	田径场地: 0.6-2.5mm	平均值 1.8mm (田径场地, 符合 0.6-2.5mm 要求)	合格
抗滑值	-	≥ 47 (BPN, 20°C时)	52BPN (20°C时, ≥ 47 BPN)	合格
拉伸强度	-	非渗水型面层 ≥ 0.5 MPa	0.65MPa (非渗水型面层, ≥ 0.5 MPa)	合格
拉断伸长率	-	$\geq 40\%$	55% ($\geq 40\%$)	合格
阻燃性能	-	达到阻燃 1 级, 即燃烧时间 ≤ 3 s, 燃烧距离 ≤ 150 mm	燃烧时间 1.5s, 燃烧距离 80mm (达到阻燃 1 级, 燃烧时间 ≤ 3 s, 燃烧距离 ≤ 150 mm)	合格
耐老化性能	-	老化后拉伸强度和拉断伸长率仍应符合未老化时的标准要求	老化后拉伸强度 0.62MPa, 拉断伸长率 52% (仍符合未老化时标准要求)	合格
无机填料含量	-	$\leq 65\%$	58% ($\leq 65\%$)	合格
有害物质限量	3 种邻苯二甲酸酯类化合物 (DBP、BBP、DEHP) 总和	≤ 1.0 g/kg	0.6g/kg	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202500711A3129

	3 种邻苯二甲酸酯类化合物 (DNOP、DINP、DIDP) 总和	≤1.0g/kg	0.5g/kg	合格
	18 种多环芳烃总和	≤50mg/kg	35mg/kg	合格
	苯并 (a) 芘	≤1mg/kg	0.6mg/kg	合格
	短链氯化石蜡 (C10-C13)	≤1.5g/kg	1.2g/kg	合格
	4,4'- 二氨基 - 3,3'- 二氯二苯甲烷 (MOCA)	≤1.0g/kg	0.7g/kg	合格
	游离甲苯二异氰酸酯 (TDI) 和游离六亚甲基二异氰酸酯 (HDI) 总和	≤10g/kg	8.2g/kg	合格
	游离二苯基甲烷二异氰酸酯 (MDI)	≤10g/kg	7.5g/kg	合格
	可溶性铅	≤90mg/kg	35mg/kg	合格
	可溶性镉	≤10mg/kg	3mg/kg	合格
	可溶性铬	≤10mg/kg	2.5mg/kg	合格
	可溶性汞	≤2mg/kg	0.8mg/kg	合格
有害物质释放量	总挥发性有机物 (TVOC) 释放量	≤5mg/(m ² ·h)	3.2mg/(m ² ·h)	合格
	甲醛释放量	≤0.4mg/(m ² ·h)	0.25mg/(m ² ·h)	合格
	苯释放量	≤0.1mg/(m ² ·h)	0.06mg/(m ² ·h)	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
 Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202500711A3129

	甲苯、二甲苯和乙苯 总和释放量	$\leq 1.0\text{mg}/(\text{m}^2\cdot\text{h})$	$0.7\text{mg}/(\text{m}^2\cdot\text{h})$	合格
	二硫化碳释放量	$\leq 7\text{mg}/(\text{m}^2\cdot\text{h})$	$5.2\text{mg}/(\text{m}^2\cdot\text{h})$	合格
气味	-	≤ 3 级	气味等级 2 级	合格

(二) 胶粘剂

检测项目	子项目	检测结果	技术要求	单项判定
有害物质含量	3 种邻苯二甲酸酯类 化合物 (DBP、BBP、 DEHP) 总和	0.7g/kg	$\leq 1.0\text{g}/\text{kg}$	合格
	3 种邻苯二甲酸酯类 化合物 (DNOP、 DINP、DIDP) 总和	0.6g/kg	$\leq 1.0\text{g}/\text{kg}$	合格
	游离甲苯二异氰酸酯 (TDI) 和游离六亚甲 基二异氰酸酯 (HDI) 总和	8.5g/kg	$\leq 10\text{g}/\text{kg}$	合格
	短链氯化石蜡 (C10-C13)	1.2g/kg	$\leq 1.5\text{g}/\text{kg}$	合格
有害物质释放量	总挥发性有机物 (TVOC) 释放量	8.2g/L	$\leq 10\text{g}/\text{L}$	合格
	甲醛释放量	0.7g/kg	$\leq 1.0\text{g}/\text{kg}$	合格
	苯释放量	0.15g/kg	$\leq 0.2\text{g}/\text{kg}$	合格
	甲苯、二甲苯和乙苯 总和释放量	8.5g/kg	$\leq 10\text{g}/\text{kg}$	合格

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司
 Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI202500711A3129

	二氧化碳释放量	2.3g/kg	≤3g/kg	合格
气味	-	气味等级 2 级	≤3 级	合格

六、综合结论

本次检测的预制型塑胶跑道面层（用于田径场地，非渗水型）及配套胶粘剂的各项检测项目结果均符合 GB36246-2018《中小学合成材料面层运动场地》标准要求，综合判定为合格。

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com

检测合格



注 意 事 项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com