



检测报告

Test Report

委托单位: 广西好味一家餐饮管理有限责任公司

样品名称: 油烟检测

检验类别: 委托检验

厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co.Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI20251202A1056

样品名称	: 油烟检测	型号规格	: /
商标	: /	样品数量	: 1 pcs
委托单位	: 广西好味一家餐饮管理有限责任公司		
委托单位地址	: 广西壮族自治区南宁市青秀区凤岭南路 16 号保利·领秀前城领秀府 6 号楼 11 号楼 12 号楼 (商业) 二层 202 商铺		
生产单位	: 广西好味一家餐饮管理有限责任公司		
生产单位地址	: 广西壮族自治区南宁市青秀区双拥路 14 号 (广西壮族自治区卫生健康委员会幼儿园)		
检验类别	: 委托检验	测试日期	: 2025 年 11 月 25 日-2025 年 12 月 02 日
签发日期	: 2025 年 12 月 02 日		
检验依据	: 根据客户要求依据标准对送检样品进行了检测, 具体检测项见后续页。		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 63.8%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制:

张华伟

报告审核:

杨泽群

报告签发:

杨泽群

检测专用章

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址: 福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com



报告编号: HYI20251202A1056

一、样品基本情况:

表 1 样品基本情况

样品类别	样品名称	采样点位	采样频次		采样人员	采样时间	收样人员	收样时间	分析时间
			天数	次/天					
有组织废气	油烟	厂界上风向二个点	1	1	郭浩	2025.11.25	王明轩	2025.11.25	2025.11.25-2025.12.02
		厂界下风向三个点	1	1	郭浩	2025.11.25	王明轩	2025.11.25	2025.11.25-2025.12.02

二、生产工单编号、检测类别、项目、方法、设备

表 2 检测分析方法及主要仪器设备一览表

样品类别	检测项目	检测方法	检测和分析设备	仪器编号	分析人员	最低检出限
废气 (有组织)	油烟	固定污染源油烟和油雾的测定 红外分光光度法 HJ1077-2019	智能综合采样器 ADS.2062E(2.0)	04789	文军	-----
			低浓度称量恒温恒湿设备 JNVN.800S	04752	文军	4mg/L
			十万分位天平 MS105DU	04753	文军	0.06mg/L
			万分位天平 ME 204	04774	文军	0.025mg/L
			电热恒温鼓风干燥箱 DHG.9203A	04778	文军	0.01mg/L
			红外测油仪 OIL 480	04711	文军	4mg/L
			紫外分光光度计 UV.1100	04752	文军	0.002mg/m ³
			紫外可见分光光度计 UV.1800PC	04752	文军	/

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



三、检测结果

采样日期	检测因子	检测点位	检测结果	单位
2025. 11. 25	油烟	油烟净化器出口 1#	1.16	mg/m ³
		油烟净化器出口 2#	1.34	mg/m ³
		油烟净化器出口 3#	1.75	mg/m ³
		油烟净化器出口 4#	1.62	mg/m ³
		油烟净化器出口 5#	1.49	mg/m ³

*****以下空白*****

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.





注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主任、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仅对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com