



检测报告

Test Report

送检企业: 福州德予善丰贸易有限公司

样品名称: 有芯卫生卷纸

检验类别: 委托检验


厦门泓益检测有限公司

Xiamen Hongyi Testing Technology Co. Ltd

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202601140A1360A196

样品名称	: 有芯卫生卷纸	样品型号	: 105mm×120mm×10 卷(5层)140克/卷
商标	: 津洁	样品类别	: /
委托单位	: 福州德予善丰贸易有限公司		
委托单位地址	: 福建省福州市仓山区南二环路 730 号双湖新城二区 15 栋 (双湖新城商贸楼) 6 层 652 室		
生产单位	: /		
生产单位地址	: /		
样品数量	: 4 卷	测试日期	: 2026 年 01 月 07 日-2026 年 01 月 14 日
签发日期	: 2026 年 01 月 14 日		
检验依据	: GB/T 20810-2018 《卫生纸(含卫生纸原纸)》		
检验项目	: 见后续		
样品特征和状态	: 完好		
环境温度	: 24.6℃	环境湿度	: 62%
测试结果	: 本次委托检验, 所检项目全部符合标准要求		

报告编制: 张华伟

报告审核: 杨泽群



This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.



报告编号: HYI202601140A1360A196

检测项目	单位	技术指标	检测结果	判定	检测方法	
定量	g/m ²	16.0±1.0	16.2	合格	GB/T24328.5-2009	
D65 亮度	%	≤90.0	85.5	合格	GB/T 7974-2013	
横向吸液高度(成品层)	mm/100s	≥30	86	合格	GB/T461.1-2002	
抗张指数	纵向	≥3.50	6.05	合格	GB/T 24328.3-2020	
	横向	≥1.80	4.34	合格		
柔软度(成品层纵横平均)	mN	≤250	249	合格	GB/T 8942-2016	
可迁移性荧光物质	—	无	无	合格	GB/T 20810-2018 中 6.7 条	
灰分[原生木浆(纤维)]	%	≤1.0	0.32	合格	GB/T 742-2018 灼烧温度:(575±25)℃	
球形耐破度(成品层)	N	≥1.50	5.56	合格	GB/T 24328.7-2020	
掉粉率	%	≤0.50	0	合格	GB/T 20810-2018 附录 B	
交货水分	%	≤10.0	7.9	合格	GB/T 462-2023	
洞眼	总数	≤20	0	合格	GB/T 20810-2018 中 6.11 条	
	2mm~5mm	≤20	0	合格		
	>5mm, ≤8mm	≤2	0	合格		
	>8mm	不应有	0	合格		
尘埃度	总数	≤50	0	合格	GB/T 1541-2013	
	0.2 mm ² ~1.0mm ²	≤50	0	合格		
	>1.0 mm ² , ≤2.0mm ²	≤10	0	合格		
	>2.0 mm ²	不应有	0	合格		
细菌菌落总数	CFU/g	≤600	8	合格	GB/T 20810-2018 附录 C	
大肠菌群	—	不得检出	未检出	合格		
金黄色葡萄球菌	—	不得检出	未检出	合格		
溶血性链球菌	—	不得检出	未检出	合格		
偏斜度	mm	≤3	0	合格	GB/T451.1-2002	
尺寸偏差	宽度偏差	mm	不超过±3	0	合格	GB/T 20810-2018 中 6.18.2.2 条
	节距偏差	mm	不超过±5	1	合格	GB/T 20810-2018 中 6.18.2.3 条
外观质量	—	纸面皱纹应均匀, 纸面应洁净, 不应该有异味和异物, 不应有明显的残缺、破损、硬质块、生草筋、浆团等纸病和杂质。	符合要求	合格	GB/T 20810-2018 中 6.19 条	
尺寸	mm	103mm(±3)*123mm(±3)	103mm*124mm	合格	GB/T 20810-2018	
克重	g/卷	138g/卷±6g*10 卷	140g/卷*10 卷	合格	GB/T24328.5-2009	
纸张层数	层	5 层	5 层	合格	GB/T 24328.2-2020	

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.





注意事项:

1. 报告无“检验报告章”或检验单位公章无效。
2. 未经本实验室书面同意,不得部分复制本报告。
3. 报告无主检、审核、批准人签字无效。
4. 报告涂改无效。
5. 对检测报告若有异议,应于收到报告之日起十五日内向检测单位提出,逾期不予受理。
6. 委托检测仪对来样负责。

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

Add: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

报告结束

This report shall not be altered, increased or deleted. The results shown in this test report refer only to the sample(s) tested. Without written approval of Hongyi Testing, this test report shall not be copied except in full and published as advertisement Hongyi Physical & Chemical Lab.

厦门泓益检测有限公司

Xiamen Hongyi Testing Co., Ltd.

地址:福建省厦门市同安区轻工食品工业区美禾路 99 号

ADDRESS: No. 99 Meihe Road, Light Industry Food Industrial Zone, Tongan District, Xiamen City, Fujian Province,

邮箱: hongyotest@123.com